

10432-28
all cancelled
7-25-01




FIG. 1




FIG. 2

FIG. 3




FIG. 4




FIG. 5 A




FIG. 5 B




FIG. 5C




FIG. 5D




FIG. 6A




FIG. 6B




FIG. 6C

Table 1: Example of a MediaExit Pattern

Page Identifier	Printing Indicator	Output Destination
4	True	second output dest.
8	True	second output dest.
12	True	second output dest.
13	True	first output dest.

09694734-102300

FIG. 7A




FIG. 7B




FIG. 7C

Table 2: Example of a Balanced MediaExit Pattern

Page Identifier	Printed On?	Output Destination
4	True	second output destination
8	False	first output destination
8	True	second output destination
12	False	first output destination
12	True	second output destination

09694734-102300

FIG. 7D

Table 3: Example of an Unbalanced MediaExit Pattern

Page	Printed On?	Output Destination
4	True	<JobExit>
8	True	<JobExit>
12	True	<JobExit>
last	False	Output Destination1
last	False	Output Destination1

FIG. 8





FIG. 9



THE JOURNAL OF THE




FIG. 11

FIG. 11 is a screenshot of a software interface for defining a media exit pattern. The interface includes several labeled components:

- 102**: Paper: ▼ TabA
- 105**: Exception Mode: ▼ <Duplex>
- 304**: MediaExit Pattern DefinePattern ▼
- 103**: Page List: 4,8,12
- 107**: Insert ▼
- 104**: A preview window showing 'TabA [648 792] White Plain 120 gsm'.
- 305**: A large empty rectangular area for defining the pattern.

FIG. 13

FIG. 13 is a screenshot of a software interface for creating a new insert. The interface includes several labeled components:

- 352**: A preview window showing 'TabA [648 792] White Plain 120 gsm'.
- 359**: Create New Insert
- 360**: Use <JobExit>
- 361**: Use "Exit1"
- 362**: Use "Exit2"
- 363**: A grid of radio buttons for selecting options.
- 367**: Set "Exit1" to top ▼
- 353**: Set "Exit2" to top ▼
- 364**: OK
- 365**: Reset
- 366**: Cancel
- 355**, **356**, **357**, **358**: Lines indicating connections to the radio button grid.

10

15

20

25343